

# Verktøy tabell

Merking	Hardhet								Bruksområde
	SSS	SS	S	M	L	X	XX	XXX	
Gull 6/8	x	x	x	x	x	x	x	x	Epoxi, lim asfalt acryl
Sølv 8/12	x	x	x	x	x	x	x	x	Epoxi, lim asfalt acryl
Svart 14/16	x	x	x	x	x	x	x	x	Grovsliping, oljespill
Brun20/25	x	x	x	x	x	x	x	x	Betonggulv, oljespill
Blå 30/40	x	x	x	x	x	x	x	x	Avretting ren betong
Grønn 60/80			x	x	x				Finsliping
Rød 100/120			x	x	x				Finsliping
Hvit 200/230			x	x	x				Finsliping
Orange 270/325				x					Finsliping
Gul 400/500				x					Polering
Beige 800				x					Polering
Himmel 1500				x					Polering
Grå 3000				x					Polering
Lilla 5000				x					Polering

Myke segment			Medium segment		Harde segment		
<b>SSS</b>	<b>SS</b>	<b>S</b>	<b>M</b>	<b>L</b>	<b>X</b>	<b>XX</b>	<b>XXX</b>
Hard betong			Normal betong		Porøs betong		



“NÅR DET GJELDER DIAMANTVERKTØY OG MASKINER FOR ARMERT BETONG”

**SCAN-DIAMANT AS**

Sollihøgden 19 • N-7374 Røros • Tlf 72 41 27 02 • Fax 72 41 01 35 • Mobil 917 39 665  
Etter kontortid 72 41 28 33 • E-post: [posti@scandiamant.no](mailto:posti@scandiamant.no) • [www.scandiamant.no](http://www.scandiamant.no)